

# instrukcja obsługi user's manual



eng

pl



## NVC-GDN3803H/IRH-2/LPR

# NOVUS®

**UWAGI I OSTRZEŻENIA****SAFEGUARDS AND WARNINGS**

---

---

## UWAGA!

Kamery NVC-GDN3803H/IRH-2/LPR dostarczane są z ustawieniami zoptymalizowanymi pod kątem funkcji LPR. Należy mieć na uwadze że przywrócenie z menu kamery ustawień domyślnych skasuje ich zoptymalizowaną wersję.

**Dlatego w celu zachowania funkcjonalności nie zaleca się zmiany ani przywracania ustawień fabrycznych kamery!**

Jeśli ustawienia zostały zresetowane do wartości fabrycznych, należy ręcznie ustawić następujące parametry:

**Migawka ręczna: 1/500, AGC: wył, D&N: Auto, DNR: wył., HLC: wł.**

Pozostałe parametry powinny być ustawione jak w kamerze NVC-GDN3803H/IRH-2 której wersja LPR jest wyspecjalizowanym analogiem.

## ATTENTION!

NVC-GDN3803H/IRH-2/LPR cameras are shipped with settings optimized for performing the LPR function. Please note that restoring factory defaults from camera menu will overwrite its customized version.

**In order to preserve the functionality, changing settings as well as restoring factory defaults is not recommended!**

If settings have already been re-set to their defaults, please manually set the following parameters:

**Manual shutter: 1/500, AGC: off, D&N: Auto, DNR: off., HLC: off.**

Other parameters should be set as in NVC-GDN3803H/IRH-2, that the LPR version is a specialized analogue.