



6. External dimensions (in millimeters) / Wymiary zewnętrzne (w milimetrach)



Bottom view  
Widok od spodu

Side hole    Base    Cover  
Otwór boczny    Podstawa    Pokrywa



Top view  
Widok z góry

### 1. Introduction

Wall/ceiling internal/external mount bracket NVB-3025JB is designed for IP camera series 3000. A complete list of compatible cameras is available in the product data sheet on <http://www.novuscctv.com/en>.

### 2. Package contents

- Wall / ceiling mount bracket 1 pc
- Mounting screws/sleeves 1 set
- Camera mounting screws 1 set
- Mounting template 1 pc
- Foam gasket 1 pc

### 3. Technical specification

|               |   |
|---------------|---|
| Bracket type  | Wall/ceiling mount bracket, internal/external |
| Material      | Aluminium                                     |
| Colour        | White   |
| Load capacity | 10 kg   |
| Dimensions    | Detailed dimensions showed on diagram         |
| Weight        | 0,35 kg                                       |

### 4. Installation manual

1. Pick a suitable location and provide all necessary wiring in desired bracket mounting place.
2. Mark 4 mounting holes and drill them in selected locations (optionally use mounting template).
3. Stick foam gasket to back side of bracket (base).
4. Plug unused holes with attached end caps and if required, please seal it with appropriate sealing mass.
5. Put all cables through one of available holes and screw the bracket to the wall. It is recommended to mount bracket so label "UP" is directed upwardly.
6. Connect cables to the camera.
7. Screw the camera to the adapter using the appropriate screw and holes, according to the table on the other page.

**Notice:** Method of mounting camera (to base or cover) depends on the camera model. Details about location of installation are given in table on the other page.

### 1. Charakterystyka produktu

Adapter ścienny/sufitowy wewnętrzny/zewnętrzny, wykonany z aluminium pokrytego powłoką proszkową w kolorze białym, przeznaczony do kamer IP serii 3000. Pełna lista kamer kompatybilnych z adapterem NVB-3025JB dostępna jest w karcie produktu na stronie <http://www.novuscctv.com/pl>

### 2. Zawartość zestawu

- Adapter ścienny/sufitowy 1 szt.
- Wkręty/kołki montażowe adaptera 1 kpl.
- Wkręty do montażu kamery 1 kpl.
- Szablon montażowy 1 szt.
- Uszczelka piankowa 1 szt.

### 3. Dane techniczne

|          |   |
|----------|---|
| Typ      | Adapter ścienny/sufitowy, wewnętrzny/zewnętrzny |
| Materiał | Aluminium                                       |
| Kolor    | Biały   |
| Nośność  | 10 kg   |
| Wymiary  | Szczegółowe wymiary na rysunkach                |
| Masa     | 0,35 kg   |

### 4. Instrukcja montażu

1. Wybrać odpowiednią lokalizację i doprowadzić wszystkie niezbędne przewody do przyszłego podłączenia kamery.
2. Oznaczyć miejsce montażu, a następnie zaznaczyć i wywiercić 4 otwory pod śruby montażowe (można skorzystać z szablonu montażowego dołączanego do uchwytu).
3. Nakleić na podstawie uchwytu uszczelkę piankową.
4. Zaślepić nieużywane otwory zaślepkami z wyposażenia i w razie potrzeby uszczelnić dodatkowo masą uszczelniającą.
5. Przeprowadzić przewody przez jeden z dostępnych otworów i przykręcić adapter do ściany tak, by znacznik „UP” był skierowany do góry.
6. Podłączyć przewody do kamery.
7. Przykręcić kamerę do adaptera wykorzystując odpowiednie śruby i otwory, zgodnie z tabelą na jednej z kolejnych stron.

**Uwaga:** Sposób mocowania kamery (do podstawy lub pokrywy) zależy od jej modelu. Szczegóły dotyczące miejsca montażu zamieszczone są w tabeli na jednej z kolejnych stron.

## 5. Summary of installing the camera and selection of appropriate screws Zestawienie miejsc montażu kamery i dobór odpowiednich śrub

| Model of camera<br>Model kamery | Location<br>Miejsce montażu | Screws type<br>Typ śrub |
|---------------------------------|-----------------------------|-------------------------|
| NVIP-4DN3512H/IR-1P             | Cover / Pokrywa             | M4x11                   |
| NVIP-3DN7540H/IRH-2P            |                             |                         |
| NVIP-xDN3030H/IR-1P             |                             |                         |
| NVIP-xDN3031H/IR-1P             |                             |                         |
| NVIP-xDN3000H/IR-1P             |                             |                         |
| NVIP-4DN3060H/IR-1P             |                             |                         |
| NVIP-4DN3061H/IR-1P             |                             |                         |
| NVIP-3DN3050H/IR-1P             |                             |                         |
| NVIP-2DN7460H/IR-2P             |                             |                         |
| NVIP-8DN7560H/IR-2P             |                             |                         |
| NVIP-4DN3511H/IR-1P             |                             |                         |
| NVIP-5DN3512H/IR-1P *           | Base / Podstawa             | M4x16*                  |
| NVIP-1DN3040H/IR-1P *           |                             |                         |
| NVIP-4DN3513H/IR-1P *           |                             |                         |
| NVIP-xDN3031V/IR-1P             | Base / Podstawa             | M4x22                   |
| NVIP-4DN3513V/IR-1P             |                             |                         |
| NVIP-4DN3061V/IR-1P             |                             |                         |
| NVIP-xDN3033V/IR-1P             | Cover / Pokrywa             | M4x9                    |

\*For mounting a camera, use screws from cover.

\*Do przykręcenia kamery należy użyć śrub mocujących pokrywę